

COMPATIBILITY CHART Li-Ion Powerman UL800 version 1 & 2

Brand	Battery	Charge with PLATE	POWERMAN Available	POWERMAN Itemnumber
CANON	BP-2LH / BP-608 / BP-617 / NB-2L	A		
	NB-1L / NB-1LH	C		
	BP-406 / BP-412 / BP-422	D		
	BP-511 / BP-512 / BP-522 / BP-535 / BP-911 / BP-914 / BP-915 / BP-941 / BP-924 / BP-927 / BP-930 / BP-945	BASE	BP-511/512	14
	BP-2L12 / BP-3LCL / BP-407 / NB-1L / NB-1LH / NB-2F12 / NB-2L / NB-3L	UNIVERSAL version 1+2	NB-1L NB-2L NB-3L	11 13 12
	NB-4L	UNIVERSAL version 2		
CASIO	NP-20 / NP-30 / NP-40	UNIVERSAL version 1+2	NP-20 NP-30 NP-40	30 32 31
FUJI	NP-80	A		
	DR-LB4 / NP-40 / NP-60 / NP-80 / NP-100 / NP-120	UNIVERSAL version 1+2	NP-40 NP-60 NP-80 NP-100	31 32 33 34
	NP-30	UNIVERSAL version 2		
HITACHI	VM-BPL13 / VM-BPL27 / VM-BPL30 / VM-BPL60 / VM-E330 / VM-E535 / VM-N520 / VM-	BASE		
JVC	BN-V712 / BN-V714	A		
	BN-V607 / BN-615 / BN-628 / BN-V907	B		
	BN-507 / BN-514 / BN-V214 / BN-V207	C		
	BN-V107 / BN-V114	D		
	BN-V408 / BN-V416 / BN-V428 / BN-V812 / BN-V814	BASE		
	BN-V101 / BN-V306 / BN-V312 / BN-V312U	UNIVERSAL version 1+2		
	BN-VF707 / BN-VF714 / BN-VF733	UNIVERSAL version 2		
KODAK	KLIC-3000	A		
	KLIC-3000 / KLIC-5000 / KLIC-5001	UNIVERSAL version 2		
KONICA/MINOLTA	NP-800	C		
	DR-LB1 / DR-LB4 / NP-1 / NP-200 / NP-400 / NP-600 / NP-800 / NP-900	UNIVERSAL version 1+2	DR-LB1 DR-LB4	40 41
	NP-700	UNIVERSAL version 2		
KYOCERA	BP-800S / BP-1000S	UNIVERSAL version 1+2		
NIKON	EN-EL1	C	EN-EL1	20
	EN-EL1 / EN-EL2 / EN-EL3 / EN-EL5 / EN-EL8	UNIVERSAL version 1+2	EN-EL1 EN-EL2 EN-EL3 EN-EL5	20 21 23 22

COMPATIBILITY CHART Li-Ion Powerman UL800 version 1 & 2

Brand	Battery	Charge with PLATE	POWERMAN Available	POWERMAN Itemnumber
OLYMPUS	BP-LM1 / LI-10B / LI-12B / LI-20B / LI-40B / PS-BLM1	UNIVERSAL version 1+2	LI-10B	50
PANASONIC	CGP-110E / CGP-120E / CGP-145 / CGP-165 / CGP-285 / CGP-D14 / CGP-D16 / CGP-D21 / CGP-D28 / CGR-D08A / CGR-D105 / CGR-D110 / CGR-D120 / CGR-D16A / CGR-D210 / CGR-D220 / CGR-D320 / CGR-S101A / CGR-S301A / CGR-S602A / CGR-S602E / VW-VBD21 / VW-VBD23 / VW-VB	B		
	CGR-V14 / CGR-V26 / CGR-V610 / CGR-V620E	C		
	AG-BP15P / AG-BP25 / CGR-B202A / PV-DBP5 / VW-VBD1 / VW-VBD1E / VW-VBD2	BASE		
	CGA-DU07 / CGA-DU14 / CGA-DU21 / CGA-S001E / CGA-S002 / CGA-S004 / CGA-S006E / CGR-101 / CGR-602A / CGR-D120 / CGR-D28A / CGR-D53A / CGR-S602E / DMW-BC7 / DMW-BCA7 / DMW-BCB7 / DMW-BL14 / DMW-BMA7 / DMW-BM7 / VW-VBA05 / VW-VBA10 / VW-VBAP10 / VW-VBD07 / V	UNIVERSAL version 1+2	DMW-BM7	60
	CGA-S005 / DMW-BCC12	UNIVERSAL version 2		
PENTAX	D-L12 / D-L17 / D-L18	UNIVERSAL version 1+2		
POLAROID	PR-105DG / PR-110DG / PR-111DG	UNIVERSAL version 1+2		
RCA	BB-075 / BB-075L	A		
	BB-065L	BASE		
RICOH	DB-30 / DB-40 / DB-43 / NP-40	UNIVERSAL version 1+2	NP-40	31
	DB-60	UNIVERSAL version 2		
SAMSUNG	SB-L160 / SB-L320 / SB-L480	BASE		
	SB-L0737 / SB-L1137	UNIVERSAL version 1+2		
SANYO	UR-421	C		
	VM-LC100	BASE		
	DB-L10 / DB-L20 / UR-211 / UR-421	UNIVERSAL version 1+2		
SHARP	BT-L1 / BT-L2 / BT-L11 / BT-L12 / BT-L22 / VR-BL71 / VR-BL75 / VR-BL81	A		
	BT-L221 / BT-L441 / BT-L241 / BT-L41 / VR-BL91	B		
	BT-L31 / VR-BL72	C		
	AD-S30BT / AD-S31BT / AD-T50BT / AD-T51BT	UNIVERSAL version 1+2		

COMPATIBILITY CHART Li-Ion Powerman UL800 version 1 & 2				
Brand	Battery	Charge with PLATE	POWERMAN Available	POWERMAN Itemnumber

COMPATIBILITY CHART Li-Ion Powerman UL800 version 1 & 2

Brand	Battery	Charge with PLATE	POWERMAN Available	POWERMAN Itemnumber
SONY	NP-500 / NP-520 / NP-F10 / NP-F20 / NP-F30 / NP-F100 / NP-F200 / NP-F300 / NP-F330 / NP-F530 / NP-F550 / NP-F720 / NP-F730 / NP-F730H / NP-F750 / NP-F750SP / NP-F930 / NP-F950 / NP-F960 / NP-FC10 / NP-FC11 / NP-FF50 / NP-FF70 / NP-FM50 / NP-FM70 / NP-LIP-4WM / LIP-10 / NP-FE1 / NP-FR1 / NP-FT1	BASE	NP-F550/330 NP-FM50 NP-FC10/11 NP-FS10/11	1 2 3 4
		UNIVERSAL version 1+2		
THOMSON	BAT600	BASE		
TOSHIBA	PDR-BT1 / PDR-BT2	A		
	PDR-BT1 / PDR-BT2 / PDR-BT3 / PDR-BT9	UNIVERSAL version 1+2		